



# LG VM720 Volume Button Removal

The following guide aims to show the user the steps required to remove the volume button.

Written By: Abdul Rehman Farrukh



## INTRODUCTION

The LG VM720 is a fairly easy device to handle. Any user with the right set of tools and a basic knowledge of mobile device should be able to fix/replace components related to normal wear and tear.



### TOOLS:


- [iFixit Opening Tools](#) (1)
-

## Step 1 — Power Button Removal



- Remove the back cover followed by removing the battery.

## Step 2



- With the back panel exposed, begin by removing 10 screws located at the back side of the phone.





### Step 3



- Using a sharp tool, loosen the edges and slowly detach the front screen panel from the back panel.

### Step 4



- With the back panel removed, use a screwdriver to remove the power button gently on the inside so it comes off from the back casing.

To reassemble your device, follow these instructions in reverse order.

